

FIG. 1




FIG. 2





FIG. 3

APPLICATION TYPE	BROWSER	MAIL	TELEPHONE APPLICATION
PRIORITY LEVEL	2	2	1

FIG. 4

	BROWSER	MAIL	TELEPHONE APPLICATION
LOUDSPEAKER	2	2	1
DISPLAY	3	2	1
COMMUNICATION CONNECTION	1	1	2
LED	2	3	1

FIG. 5



F I G . 6

APPLICATION TYPE	STATE OF USE	POINTER TO RESOURCE INITIALIZATION FUNCTION	EVENT NOTIFICATION
BROWSER	USING LED	N U L L	NOT NECESSARY
MAILER	USING VIBRATOR	Func *MailFuncSetResource(resource_type)	NOTIFY UPON SURRENDER OF RESOURCE
MELODY PLAYER	WAS ONCE USING, BUT SURRENDERED MIDI DEVICE DURING USE	Func *MelodyFuncSetResource(resource_type)	NOTIFY UPON SURRENDER OF RESOURCE
TELEPHONE APPLICATION	USING MIDI DEVICE	Func *NormalResetFunc(resource_type)	NOT NECESSARY

FIG. 7




FIG. 8




FIG. 9






FIG. 10




FIG. 11

LIBRARY TYPE	LIBRARY A	LIBRARY B	LIBRARY C
PRIORITY LEVEL	1	3	1

FIG. 12




FIG. 13




FIG. 14 PRIOR ART




FIG. 15 PRIOR ART

